# **SCM Switch with SCR Series Underwater Lights**



## **HOW TO OPERATE**

#### Power Toggle Control

Step to the next color or brightness level.

#### **Push Button Control**

Press button to access light 'Modes' such as fade and strobe.

### **RECOMMENDED WIRE GAUGES**

Scan the QR Code or click **here** to view our recommended wire gauge chart.




SCM-SWITCH-O/O/ MOMENTARY SCR Series Underwater Light
SCM-Switch-O/O/MOMENTARY (20A Max)

2x SCR 24s at 10A each or 3x SCR-16s at 6.4A each

To Power

Source

Shadow-NET wires are not connected when using a switch.



2	Power Switch
3	Switch LED
5	Momentary O
6	Momentary I
7	GND
8	Power Switch

NAME

PIN

Ground